

INSTALLATION GUIDE

ACROBAT | DOWNLIGHT

READ AND FOLLOW ALL SAFETY INSTRUCTIONS! SAVE THESE INSTRUCTIONS AND DELIVER TO OWNER AFTER INSTALLATION.

⚠ WARNING: RISK OF ELECTRIC SHOCK

- Before installation, servicing, or performing routine maintenance **DISCONNECT POWER BY TURNING OFF THE CIRCUIT breakers both to the outlet box and to its associated wall switch.**
- Installation and service of luminaires should be performed by a qualified licensed electrician in accordance with all local and National Electrical Codes.
- **DO NOT** install damaged product
- Verify that supply voltage is correct by comparing it with the luminaire label information.
- All wiring connections should be capped with UL approved recognized wire connectors

⚠ WARNING: RISK OF INJURY

- Allow luminaire to cool before servicing and performing maintenance.
- Follow all manufacturer’s warning and restrictions for driver type, mounting locations, replacement and recycling.
- Wear safety glasses and gloves when installing, maintaining or servicing.
- Avoid direct eye exposure to the light source while it is on.

⚠ WARNING: RISK OF PRODUCT DAMAGE

- Never connect components under load
- Do not touch the yellow surface of the LED as it may damage the light engine


⚠ WARNING

- **DO NOT** separate any other wires that may be in the box.
- **DO NOT** damage the insulation of older wiring.
- In regular circumstances the **BLACK** wire will be the “Hot” lead and the **WHITE** wire will be the “Neutral” or “Common” lead. A **GREEN** or **BARE COPPER** wire is “Ground”. In older buildings, it is always good practice to reconfirm the polarity of the wiring.

NOTICE

- This fixture is designed to be mounted on a correctly installed standard round or octagon box. The box must be securely mounted to the structure of the building. The cover plate and hardware supplied should be used. Directly mounting the fixture to the outlet box may make it impossible to correctly align the fixture.


TOOLS REQUIRED




FLAT HEAD
SCREWDRIVER



SIZE 1 PHILLIPS
SCREWDRIVER



HOLE SAW
(OR SPEED ROUTER)




DRYWALL SAW


INSTALLATION GUIDE

ACROBAT | DOWNLIGHT

STEP 1 - CUT OUT CEILING




STEP 2 - MAKE ELECTRICAL CONNECTION




INSTALLATION GUIDE

ACROBAT | DOWNLIGHT


STEP 3 - PLACE REMODEL HOUSING IN PLENUM AREA




STEP 4 - PLACE REMODEL HOUSING IN PLENUM AREA




STEP 5 - INSTALLATION OF REMODEL DIECAST INTO CEILING



A. Attach clip to heatsink
Connect quick connect





B. Compress clips to fixture body and raise fixture into cut out. Release clips when fixture can be pushed up flush to the ceiling (C).



C. Install in ceiling

STEP 6 - ADJUSTING THE MODULE




A. Use a screwdriver and adjust tilt angle.
B. Scales on the two sides of module (6B).
C. Tighten two screws to lock tile position in place.

INSTALLATION GUIDE


ACROBAT | DOWNLIGHT

STEP 7 - OPTIC INSTALLATION




*Hex louver cannot be combined with other media

STEP 8 - TRIM INSTALLATION



Install reflector



DOWNLIGHT



ADJUSTABLE



WALLWASH