

RLM SHADE & GLOBE INSTALLATION GUIDE

**READ AND FOLLOW ALL SAFETY INSTRUCTIONS!
SAVE THESE INSTRUCTIONS AND DELIVER TO OWNER AFTER INSTALLATION.**

WARNING: RISK OF ELECTRIC SHOCK

- Before installation or servicing **DISCONNECT POWER BY SHUTTING OFF THE CIRCUIT** breakers both to the outlet box and to its associated wall switch.
- Installation and service of luminaires should be performed by a qualified licensed electrician in accordance with all local and National Electrical Codes.
- Do not install damaged product.
- Verify that supply voltage is correct by comparing it with the luminaire label information.
- All wiring connections should be capped with UL approved wire connectors.

WARNING: RISK OF INJURY

- Allow luminaire to cool before servicing.
- Follow all manufacturer's warning and restrictions for mounting locations, replacement and recycling.
- Wear safety glasses and gloves when installing, maintaining or servicing.
- Avoid direct eye exposure to the light source while it is on.

RISK OF PRODUCT DAMAGE

- Never connect components under load.

WARNING: RISK OF FIRE

- Do not separate any other wires that may be in the box.
- Do not damage the insulation of existing wiring.
- In regular circumstances the **BLACK** wire will be the "Hot" lead and the **WHITE** wire will be the "Neutral" or "Common" lead. A **GREEN** or **BARE COPPER** wire is the "Ground." In older buildings, it is always good practice to reconfirm the polarity of the wiring.

Note: Bulbs/Lamps not included.

Wall Mounted Installation:

1. Preparation:

- Feed the Line, Neutral & Ground wires from the Shade through the Arm.
- Apply thread sealing tape or compound to threaded area. Then fasten the Shade to the Arm.
- Slide the Canopy Cover over the Arm, using the 2x Set Screws with a 3/16" Hex Tool attach the Arm to the Wall Mount Bracket.

2. Mounting:

- Connect the Line, Neutral & Ground to the respective building wires using UL approved wire connectors.
- Using the screws provided mount the Fixture to a preinstalled Ø4" Round Junction Box securing the Fixture to the Wall, pushing the excess wire into the junction box.
- If needed, level the Arm using the 2x Set Screws with a 3/16" Hex Tool.
- Push the Canopy Cover over the Wall Mount Bracket's spring clips.
- If installed outdoors, apply sealant around the edge of the Canopy Cover and the opening to the Arm.

Cord Mounted Installation:

1. Cable Length Preparation:

- Using a 24mm wrench, loosen the Cable Grip to adjust the cable to the desired length leaving 8" extra for wiring.
- Tighten the Cable Grip securing it to the Canopy Cover.
- Trim the outer jacket to expose the Line, Neutral & Ground insulated wires, leaving 6" of individual wire free for wiring.

2. Mounting:

- Thread the 2x screws into the Mounting Plate for fastening the Fixture.
- Using the screws provided attach the Mounting Plate to a preinstalled Ø4" Round Junction Box securing the Mounting Plate to the Ceiling.
- Connect the Line, Neutral & Ground to the respective building wires using UL approved wire connectors, pushing the excess wire into the junction box.
- Slide the Canopy Cover over the 2x screws previously attached to the Mounting Plate and using the Ball End Nuts fasten the Canopy Cover to these screws fastening the Fixture to the Ceiling.